
PROPERTY STORMWATER DRAINAGE

OPTIONS:

- 1. Direct stormwater to your yard away from your foundation.
- 2. Direct flow to gardens, swales, ditches, soak-away pits, and towards streams, and lakes.
- 3. Underground pipes like sump pumps and foundations can connect to the underground Halifax Water Stormwater System (downspouts cannot.) Get a permit.



This is general information. Consider your specific property conditions. You may wish to consult with a professional.



- 1. Water backups and frozen pipes. Slope pipes downhill.
- 2. Flooding your neighbour.
- 3. Icing problems in the street and/or sidewalks.
- 4. Soil erosion and sediment transport.
- 5. Stormwater can not enter the Halifax Water Wastewater System.

For questions contact Halifax Water at 902.420.9287 or inflow@halifaxwater.ca



